

Access Armor Repair Kit Instructions



Kit Includes;
1 Replacement Gasket
1 Tube of Kwik Seal
1 Mini Scraper

Step 1

(A) Using provide mini scraper, remove the existing gasket. **(B)** Make sure to remove any remaining old adhesive.

Step 2

(A) Using the provided sealant/adhesive make a bead all the way around the perimeter of the panel. **(B)** Cover as much area as possible.

Step 3

Line up the new gasket using the grease seal gasket as a reference.

Step 4

(A) Press the gasket down onto the sealant firmly and evenly. **(B)** Let the gasket and adhesive set for a minimum of 2 hours before reinstalling the panel to the duct.

(1) A



(2) A



(3)



(4) A

